



ASSEMBLY INSTRUCTIONS FOR 32510/2



1. Before beginning assembly, carefully unpack and identify all parts referring to the illustration.
2. Turn off power to the installation point **OFF**. Locate the crossbar and secure it to the outlet box in the wall with (2) outlet box screws.
3. Make wires connections: Locate and attach the house ground wire to the fixture ground wire. Proceed to attach both to the crossbar with green ground screw. Using wire connectors connect the house white wire to fixture white (or ribbed side) wire; connect the house black (or red) wire to the fixture black (or smooth side) wire.
4. Carefully tuck **all** wires into the wall mounted outlet box and position the fixture over the outlet box. Align the holes in the back plate with the (2) mounting screws attached to the crossbar. Pass the fixture over the (2) mounting screws and secure by threading the (2) ball nuts onto end of screw. Hands tighten until snug.
5. Thread long stem into the coupling at fixture body, then place cover, cap, cage and big cover through the stem and secure with knurled nut and finial.
6. Thread stem into coupling at bottom of fixture body.
7. Raise big cap and small cage over the stem, and secure with knurled nut and finial.
8. Install candle sleeve over each socket.
9. Install proper bulbs (not provided) to the socket referring to the markings and labels on fixture for maximum wattage.
10. Attach crystal to the holes of big cover and fixture body as shown in the diagram.
11. Restore power to the installation point **ON**. Retain this sheet for future reference.